






- Help**
- manual on screen
- Hilfe**
- Bildschirmhandbuch
- Aide**
- manuel à l'écran
- Help**
- handleiding op het scherm
- Aluto**
- manuale su schermo
- Ayuda**
- manual en pantalla
- Справка**
- инструкция на экране
- Ayuda**
- manual en pantalla
- Ajuda**
- manual na tela
- 幫助**
- 屏幕指南
- ช่วยเหลือ**
- คู่มือผู้ใช้งานหน้าจอ



- Options**
- favourites, reorder, ...
- Optionen**
- Favoriten, neu ordnen ...
- Options**
- favoris, réorganiser, etc.
- Opties**
- favorieten, herordenen, ...
- Opzioni**
- preferiti, riordinare, ...
- Opciones**
- favoritos, reordenar ...
- Опции**
- избранное, перегруппировать, ...
- Ayuda**
- manual en pantalla
- Ajuda**
- manual na tela
- 选项**
- 收藏、重新排序...
- ตัวเลือก**
- รายการโปรด, เรียง ...



- Back**
- or previous channel
- Zurück**
- oder vorheriger Sender
- Retour**
- ou chaîne précédente
- Terug**
- of vorige zender
- Indietro**
- o canale precedente
- Atrás**
- o canal anterior
- Назад**
- или предыдущий канал
- Atrás**
- y canal anterior
- Voltar**
- e canal anterior
- 返回**
- 上一頻道
- กลับ**
- แล่ของก่อนหน้า



- Experience**
- quick settings
- Erleben**
- Schnelle Einstellungen
- Expérience**
- réglages rapides
- Hukommelse**
- snelle instellingen
- Hukommelse**
- impostazioni rapide
- Experiencia**
- configuración rápida
- Regulirovka**
- быстрые настройки
- Experiencia**
- configuración rápida
- Experiencia**
- configurações rápidas
- 体验**
- 快速设置
- การปรับ**
- การตั้งค่าอย่างรวดเร็ว



www.philips.com/tv


Non-contractual images.
Images non contractuelles.
Außervertragliche Bilder.

Specifications are subjected to change without notice.


All registered and unregistered trademarks
are property of their respective owners.

Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners
2010 © Koninklijke Philips Electronics N.V. All rights reserved.


www.philips.com




- | | |
|--|--|
| Home
- watch TV, DVD, ... | Inicio
- ver TV, DVD, ... |
| Home
- Wiedergabe von TV, DVDs... | Inicial
- asistir TV, DVD, ... |
| Accueil
- Regarder la télé, un DVD, etc. | 主页
- 观看电视 - DVD... |
| Startpagina
- kijk TV, DVD, ... | หน้า
- หน้า, หน้า ... |
| Home
- per guardare TV, DVD, ... | |
| Inicio
- ver la televisión, un DVD ... | |
| В начало
- просмотр ТВ, DVD, ... | |



- | | |
|--|--|
| Browse
- channel list, Teletext, ... | Examinar
- lista de canales, teletextos, ... |
| Durchsuchen
- Senderliste, Videotext... | Procurar
- lista canais, Teletexto, ... |
| Parcourir
- Liste des chaînes, télétexte, etc. | |
| Bladeren
- zenderlijst, teletext, ... | 浏览
- 频道列表, 图文电视... |
| Sfoglia
- elenco canali, televideo, ... | สำรวจ
- รายการ, รายการทีวี, ... |
| Buscar
- lista de canales, teletexto... | |
| Обзор
- список каналов, телетекст ... | |



- | | |
|---|---|
| Previous / Next
- channel or page | Anterior / Siguiente
- canal o página |
| Vorherig / Nächste
- Sender oder Seite | Anterior / Próxima
- canal ou página |
| Précédent / Suivant
- Chaîne ou page | |
| Vorige / Volgende
- zender of pagina | 上页 / 下页
- 频道或页 |
| Precedente / Successivo
- canale o pagina | ก่อนหน้า / ถัดไป
- ก่อนหน้า |
| Anterior / Siguiente
- canal o página | |
| Предыдущ / Следующ
- канал или страница | |



- | | |
|--|--------------------------------------|
| Navigate
- up, down, left, right | Anterior
- canal o página |
| Navigieren
- Nach oben, unten, link, re. | Anterior
- canal ou página |
| Naviguer
- haut, bas, gauche, droite | |
| Navigeren
- omhoog / omlaag / links / rechts | 导航
- 上, 下, 左, 右 |
| Naviga
- sus/juá/sinistra/destra | นำทาง
- นำ, บน, ข้าง, หน |
| Navegar
- Arriba, abajo, izquierda, derecha | |
| Навигация
- вверх, вниз, влево, вправо | |



PHILIPS
sense and simplicity